



JOYSTICK SWITCHES



BUTTON SWITCHES



DB15 CONNECTOR

Arcade style joystick and button controller.

(c) Copyright 2001 Rod Moffitt <http://rod.moffitt.info>

TITLE: arcadejoy

Document Number:

REV:
A

Date: 12/03/2001 17:52:02

Sheet: 1/1